Environmental Protection Agency

Test Cell 3 Tracer Gas Injection Procedure

This procedure is written for the Environmental Protection Agency, National Vehicle and Fuel Emissions Laboratory (NVFEL) internal use. The use of specific brand names by NVFEL in this procedure are for reference only and are not an endorsement of those products. This document may be used for guidance by other laboratories.

NVFEL Reference Number

016A

Implementation Approval

Original Procedure Authorized by EPCN #271 on 2-5-2001

Revision Description

(1) 09-18-2001 The purpose of this change is to update the Group Responsible name per EPCN #316

Table of Contents

| | 1. Purpose | 4 |
|---|---|--------------|
| | 2. Test Procedure | 4 |
| | 3. Acceptance Criteria | 16 |
| | <u>Figures</u> | |
| | Figure 1 Adapt Icon | 4 |
| | Figure 2 Restore Last File | 4 |
| | Figure 3 File to open | 5 |
| | Figure 4 Select "Schedule" then "Select Test" from Menu | 5 |
| | Figure 5 Test Select Screen | 6 |
| | Figure 6 Select "Schedule" then "Test Select" from Menu | 6 |
| | Figure 7 Enter Header Data | 7 |
| | Figure 8 Database Options | 7 |
| | Figure 9 Select "Screen" from Menu | 8 |
|] | Figure 10 Select HC Range | 8 |
|] | Figure 11 Select "Screen" from Menu | 8 |
|] | Figure 12 AVL Screen | 9 |
| 1 | Figure 13 Select Remote | 9 |

Figures Continued

| Figure 14 Select "Screen" from Menu | . 10 |
|---|------|
| Figure 15 Master Counter Timer | . 10 |
| Figure 16 Select "Screen" from Menu | . 11 |
| Figure 17 Update Emissions Background | . 11 |
| Figure 18 Insert Rosette in CVS | . 12 |
| Figure 19 Initialize Measurement Sequence | . 12 |
| Figure 20 Propane Kit | . 13 |
| Figure 21 Select "Reports" from Menu | . 13 |
| Figure 22 Data Report Setup | . 14 |
| Figure 23 Excel Spreadsheet for % Error | . 15 |

1. Purpose

The purpose of this working procedure is to describe the equipment and steps required to perform a Tracer Gas (propane) Injection Procedure

2. Test Procedure

- Turn on the test site air handling system and wait a minimum of 15 minutes for the site temperature to stabilize.
- Place a propane kit with a valid calibration sticker in the test cell and allow the kit temperature to stabilize for a minimum of 15 minutes.
- In the control room, on the computer desktop, double-click on "Adapt32" icon. See Figure 1.



Figure 1 Adapt Icon

When the "ADAPT" dialog appears, click on the "Cancel" button. See the arrow in Figure 2.




Figure 2 Restore Last File

Select "EPA_Cell3ini" from the "File to open" dialog box. See the circle in Figure 3. Click on the "Open" button. See the arrow in Figure 3.

The "ADAPT c:\adapt\epa_cell3ini" screen will appear.




Figure 3 File to open

Click on "Schedule" at the top of the screen. See the arrow in Figure 4. Choose "Select Test" from the menu. The "Test Select" box will appear.




Figure 4
Select "Schedule" then "Select Test" from Menu

On the "Select Test" dialog box, under "Select a test," choose the appropriate test: "CELL#_E.TST" or "CELL#_W.TST". See the circle in Figure 5.

Click on the "Select" button. See the arrow in Figure 5. The "ADAPT c:\adapt\epa_cell3ini" screen will return.




Figure 5
Test Select Screen

At top of the "ADAPT c:\adapt\epa_cell3ini" screen, click on "Schedule." See the arrow in Figure 6. Select "Start Test" from the menu. The "Enter Header Data" box will appear.




Figure 6
Select "Schedule" then "Test Select" from Menu

Enter the following in the "Enter Header Data" dialog box:

"Test Number:" Today's Date in yy/mm/dd format.

See arrow number 1 in Figure 7.

"Project: "tgi1" See arrow number 2 in Figure 7.

"Dyno Rotation:" "0" for East Engine, "1" for West Engine.

See arrow number 3 in Figure 7.

"Fuel Type:" Check the list next to the data entry field and enter the number

corresponding to the appropriate fuel type.




Figure 7
Enter Header Data

On the "Enter Header Data" screen, under "Database Options," click on the "OK" button. See the arrow in Figure 8. The "ADAPT c:\adapt\epa_cell3ini" screen will appear.

| | ₹ | | ┌ Database Options | | |
|---------------|----------|----------|--------------------|------------------------|------------|
| | OK_ | Cancel | Retrieve | Save to database | ┌ Auto Log |
| | | | | | |
| Test: cell3_w | , | Project: | Data Dir: C:\S` | YSTEM (State: shutdown | Tit |

Figure 8
Database Options

Click on "Screen" from the menu bar. See the arrow in Figure 9. Select "Emissions screen" from the menu options. If "Emissions screen" is not an available choice, select "More Screens" from the menu and choose "Emissions screen" from the next menu.




Figure 9
Select "Screen" from Menu

112 Click on the "HC Range" button, see the arrow in Figure 10, until "16" appears under "Range". See the circle in Figure 9.



Figure 10 Select HC Range

113 Click on "Screen" from the menu bar. See the arrow in Figure 11.




Figure 11 Select "Screen" from Menu

- Select "AVL415" from the menu options. If "AVL415" is not an available choice, select "More Screens" from the menu and choose "AVL415" from the next menu the "AVL415" screen will appear.
- On the "AVL 415" screen, use the keyboard and enter the following in the field below each header:
 - "3.000000" for "Number of Smoke Meas" label. See arrow 1 in Figure 12.
 - "1096.000000" for "Volume of Measure" label. See arrow 2 in Figure 12.
 - "6.600000" for "Time of Measure" label. See arrow 3 in Figure 12.




Figure 12 AVL Screen

On the "AVL 415" screen, select the "Remote" button. See the arrow in Figure 13.




Figure 13 Select Remote

117 Click on "Screen" from the menu bar. See the arrow in Figure 14.




Figure 14 Select "Screen" from Menu

- Select "Counter Timer" from the menu options. If "Counter Timer" is not an available choice, select "More Screens" from the menu and choose "Counter Timer" from the next menu. The "Master Counter Timer" screen will appear.
- On the "Master Counter Timer" screen, select the following 4 buttons under the "Master" button to set to the green condition:

"CVS Vmix" See arrow 1 in Figure 15.
Secondary Dilution Flow See arrow 2 in Figure 15.
Total Dilution Flow See arrow 3 in Figure 15.
Total Flow See arrow 4 in Figure 15.




Figure 15 Master Counter Timer

120 Click on "Screen" from the menu bar. See the arrow in Figure 16.




Figure 16
Select "Screen" from Menu

- Select "PNGV Run Screen" from the menu options. If "PNGV Run Screen" is not an available choice, select "More Screens" from the menu and choose "PNGV Run Screen" from the next menu. The "PNGV Run Screen" will appear.
- Go into the cell and set up the analyzer according to WP 006, PNGV Horiba Emission Analysis System Start-up / Shut Down. Ensure that the analyzer is in the sample model
- Ensure that the blower is turned on. If not turn it on by pushing the "Blower On" button on "PNGV Run Screen."
- In the control room, select the "Update Emissions Background" button on the "PNGV Run Screen." See the arrow in Figure 17. The "Background Sample Timer" will automatically start and run for 5 minutes. When the sample time returns to zero, the background level will appear in the "HC Bkgd" field. See the circle in Figure 17.




Figure 17
Update Emissions Background

Return to the test cell and insert the propane kit rosette in the dilution tunnel. See Figure 18. Set the propane kit pressure to 85 psi.



Figure 18
Insert Rosette in CVS

In the control room, select the "Initialize Measurement Sequence" from the "PNGV Run Screen" display. See the arrow in Figure 19.

The system will automatically collect the sample.




Figure 19
Initialize Measurement Sequence

When the sample collection is finished, go into the test cell and read the temperature and pressure from the propane kit. See Figure 20.



Figure 20 Propane Kit

128 Click on "Reports" from the menu bar. See the arrow in Figure 21. Select "Log Data Report" from the menu options. The "Data Report Setup" window will appear.




Figure 21 Select "Reports" from Menu

Under "Project" in the "Data Report Setup" window, select "TGI." See the circle in Figure 22. Select the "Save" Button. See the arrow in Figure 22.




Figure 22 Data Report Setup

- When the "Date" box appears, use the keyboard to enter the date followed by "TGI" in the "yy_mm_ddTGI" format. Click on the "OK" button.
- Select the "Start" button at the bottom of the display. From the menu that appears, select "Program." From the next menu, select "Excel."
- After the Excel program has loaded, select "File" from the top menu. Select "Open" from the menu that appears.
- Select the file with the path, "C:/adapt/data/TGI1."
- In the "TGI1" folder, select "TGICALC_OFFICIAL.xls."
- On the "TGICALC_OFFICIAL.xls." screen, enter the data from the test.xls screen (the Excel spreadsheet data file). When all data has been entered the recovery error will be automatically calculated and shown next to the "Recovery Error" cell.

If the percent of error displayed next to the "Recovery Error" cell. is equal to or less than $\pm 2.0\%$, the injection procedure passes. See Figure 23.

If the percent of error displayed exceeds $\pm 2.0\%$, follow this procedure and run the test a second time.

If, after the second attempt, the percent of error displayed exceeds $\pm 2.0\%$, notify a senior technician.




Figure 23
Excel Spreadsheet for % Error

Print the "TGICALC_OFFICIAL.xls." screen and file the report in the "TGI" file.

3. Acceptance Criteria

- 3.1 The test site temperature must stabilize for a minimum of 15 minutes before starting the procedure.
- 3.2 The propane kit used must have a valid calibration sticker.
- 3.3 The propane kit temperature must stabilize for a minimum of 15 minutes after it has been moved into the test site.
- 3.4 After opening the shut-off valve and adjusting the pressure to 90 ± 5 PSIA the propane tank must stabilize for a minimum of 10 minutes.
- 3.5 The percent of error displayed under "Recovery Error" on the "Propane Processor" data screen must be within $\pm 2.0\%$.